



- NOTES:**
- Install back-up rings and O-rings as shown in views.
 - When installing continuous back-up rings, use the same technique and the same care used to install O-rings.
 - When installing cartridge - be sure to torque to recommended value.