



Sun offers a general purpose handknob with lock knob control for use in systems where frequent adjustments are necessary. The handknob components are added to the basic L control. Cartridges may be ordered in this configuration from Sun by specifying a K control in the model number. Sun kits for field conversion are also available.

- NOTES:**
- Use this kit to adapt all L controls to K controls (except Series 0 and counterbalance cartridges).
 - Only for cartridges date stamped '41' or later. Lock knob snaps onto locknut furnished on cartridge.
 - Snap the lockknob onto the existing cartridge locknut.
 - Thread the handknob assembly onto the end of the adjustment screw until it bottoms out.
 - Tighten set screw against adjust screw thread.